

How to Clean Laminate Surfaces of Reveal and Madera PRO Tables

Routine Care:

To combat the existence of germs, bacteria, and viruses, the laminate surfaces of linenless tables should be cleaned daily with a solution of dishwashing liquid and warm water applied with a clean microfiber cloth.

After the initial cleaning, use an approved EPA Chemical Disinfectant to kill germs and stop the spread of disease. Here are the recommended brands for Reveal and Madera PRO tables:

- Clorox Healthcare® VersaSure® Wipes – 5 minutes of contact time
- Oxivir – 1 minute of contact time
- Virex™ II / 256 – 10 minutes of contact time
- Benefect- 10 minutes of contact time
- PDI Sani-Prime Wipes or Germicidal Spray – 3 minutes of contact time

You can also use:

- PDI Sani-Prime Germicidal Spray
- Expose II2569

If you use a product that contains bleach, it may cause some damage to the surface if it is not rinsed off completely.



Reveal Duo



Madera

Difficult Stains:

To remove stains such as coffee or tea, use a mild household cleaner and a soft bristled brush. Repeat as necessary.

If the stain persists, use a paste made from baking soda and water and apply the paste with a soft bristled brush. Scrub lightly with 10 to 20 strokes. Note that excessive scrubbing or using too much force could damage the surface, especially if it has a gloss finish.

Stubborn stains that resist any of the above cleaning methods may require the use of undiluted household bleach or nail polish remover. Apply the bleach or polish remover to the stain and let stand no longer than two minutes. Rinse thoroughly with warm water and wipe dry. The step may be repeated if the stain appears to be going away and the color of the laminate has not been affected. Be aware that prolonged exposure to bleach may cause discoloration.

Notes of Caution:

- Use a heat shield, pad, or trivet when placing hot pans and other heat-producing appliances on the tabletops to avoid potential damage.
- Avoid using acidic or abrasive cleaners as they can damage the laminate surface
- Drain cleaners containing lye will permanently damage the laminate surface (clean up all spills immediately and rinse several times with water)
- Hair and food dyes can cause permanent stains (clean up spills immediately with dishwashing detergent or an all-purpose cleaner)
- Avoid using oven cleaners (clean up spills immediately and rinse several times with water)
- Rust removers contain harsh chemicals which will quickly cause permanent damage (wipe off spills immediately and wash thoroughly with soapy water and rise several times)
- Steel wool and other abrasive pads will damage the laminate
- Toilet bowl cleaners contain harsh chemicals and can cause permanent damage (wipe up spills immediately, wash surface with soapy water and rinse several times)

Recommended Household Cleaners:

- Windex®
- Glass Plus®
- Mr. Clean®
- Formula 409®
- Fantastik®
- Isopropyl Alcohol

Avoid using cleaners with these chemicals ingredients:

- Hydrochloric acid
- Sulfuric acid
- Hydrofluoric acid
- Phosphoric acid
- Sodium hydroxide
- Pumice (abrasive)



Reveal Table Family



Madera Table Family

