



Before You Begin

- Mount the chair hanger securely to the wall with the appropriate hardware
- Locate the wall studs prior to mounting the chair hanger
- Select the correct fasteners based on the frame stud material of your buildings
- The chair hanger can hold two MeshOne® or FlexOne® Series folding chairs. It can hold up to three FlexOne Lite® folding chairs.



INSTRUCTIONS:

1. Measuring from floor to lower mount holes, chair hanger should be level and mounted at least 3 feet high
2. Mount chair hanger using #8 or #10 screws, making sure hardware is securely fastened to wall studs or door framework (screw mount holes are 16 inches apart)



**Dimensions represent distance between mount holes.*